

SACE Emax 2 - Tmax XT

Protezione pulsanti di apertura e chiusura PBC - E1.2 - XT7M

Protection covers for opening and closing push-buttons PBC - E1.2 - XT7M



Schutz der Ein- und Ausschalt-Taster PBC - E1.2 - XT7M

Protection boutons-poussoirs d'ouverture et de fermeture PBC - E1.2 - XT7M


Protección pulsadores de apertura y cierre PBC - E1.2 - XT7M

保护盖板用于打开和关闭按钮 PBC - E1.2 - XT7M


E1.2 - XT7M




1



2



3



4

