
Installation Instructions

Ground Pedestal Clamps

GPC Series




1. Remove hardware from "U" bolt and slip "U" bolt out of bracket.



2. Position "U" bolt so that the legs of the "U" bolt straddle the pedestal leg. Note: Use round "U" bolt for round pedestal leg and square "U" bolt for square pedestal leg. Round "U" bolt range: 3/4" to 1-1/8" diameter. Square "U" bolt range: 1" to 1-1/8" square.



3. Replace bracket on "U" bolt. Install hardware on "U" bolt and tighten to 75 inch-pounds.



4. Loosen the nuts for the wire connectors. Insert the wires under the connectors and tighten nuts to 75 inch-pounds.

GPC2/ORD1.75



1. Loosen hardware from "U" bolt and slip "U" bolt out of bracket.



2. Position "U" bolt so that the legs of the "U" bolt straddle the pedestal leg. Note: Use round "U" bolt for round pedestal leg and square "U" bolt for square pedestal leg. Round "U" bolt range: 1-1/8" to 1-3/4" diameter.



3. Replace bracket on "U" bolt. Install hardware on "U" bolt and tighten to 75 inch-pounds.



4. Loosen the nuts for the wire connectors. Insert the wires under the connectors and tighten nuts to 75 inch-pounds.